



F S T

PipeMic

Short instruction

1) Switch-on

Establish Bluetooth connection with headphones or Dongle




2) Desinfection



Use protection gloves!!!



Fill container



Generous spray Sensorhead

3) Prepare insertion


Close house connection valve




Remove water meter



Screw Geka-coupler



Connect hose adapter



4) Insert sonde

Insert sonde



Lock container in vertical Position



Open house connection valve completely



Push in fiber glass



5) Detect leakage

Leakage noise audible with Bluetooth headphones



OR

Aqua M-300



Frequency-characteristic and noise level visible

6) Determine position

Read length counter




Measure length



OR

Connect frequency generator



Line- or Point tracing

